

初期設定 の手順

高音も低音も極めた臨場感あふれるサウンドを体験。

● ステータスランプ

○ 接続ボタン

3

Sonos Sub Miniをお持ちのシステムに追加する



Sonosアプリを開いて[追加]をタップするか、[設定]>[システム]>[製品を追加する]に移動します。

2

Sonos Sub Miniを床に置き、電源プラグを差し込む



Sonos Sub Miniを、設定済みのSonos製品の近くの壁際や隅に置きます。

1

Sonosシステムを設定する

Sonos Sub Miniに接続するSonos製品が、すでに設定済みであることをご確認ください。



サポート

カスタマーサポート
sonos.com/support

ご利用規約、使用許諾契約
www.sonos.com/legal/terms-of-use

© 2022 Sonos, Inc. All rights reserved. Sonos*, Sonos Sub Mini, Sub Miniは、Sonos, Inc. の商標または登録商標です。*Reg. U.S. Pat. & TM Off.



640-00847 - A

ユーザーガイド
sonos.com/guides/submini

Terms of Use, License and Warranty
www.sonos.com/legal/terms-of-use

© 2022 Sonos, Inc. All rights reserved. Sonos*, Sonos Sub Mini, and Sub Mini are trademarks or registered trademarks of Sonos, Inc. *Reg. U.S. Pat. & TM Off.

SONOS

Sub Mini

English - Set Up

1. **Set up your Sonos system.** Make sure the Sonos product you plan to use with Sub Mini is already set up.
2. **Place Sub Mini on the floor and plug it in.** Place Sub Mini in a corner or near a wall, close to the speaker you'll use it with.
3. **Add Sub Mini to your system.** Open the Sonos app and tap Add, or go to **Settings>System>Add Product.**

At a glance. Hear higher highs, feel lower lows for a more immersive sound experience.

初期設定