Amp 快速入门指南

使用香蕉插头连接您 的音响

室内、室外、吊顶式或入墙式。 在设置过程中,我们会告诉您何时需要将Amp接入电源。

香蕉插头

如需了解更多信息,请参阅Sonos用户指南: sonos.com/guides/Amp

下载Sonos App 您将通过它来设置和控制Amp。







Songle Play

Download on the App Store


Songle Play

Augustine at apps amazon

已经有Sonos产品?

打开Sonos App,然后选择 更多>设置>添加音响或Sub。 畅享音乐、电视和更多内容

插入音频设备(例如唱机、CD播放器或电脑),或者 将Amp连接到电视。



使用Sonos App、电视遥控器或者Amp上的控件来控制音频。

Sonos App: 帮助和提示

网站: sonos.com/support

Twitter: @SonosSupport

电子邮件: support@sonos.com

产品用户指南:

sonos.com/guides

SONOS®

© 2018 Sonos Inc.保留所有权利。

Sonos、Amp和其他所有Sonos产品名称与宣传语都是Sonos, Inc. Sonos Reg. U.S. Pat & TM Off的商标或注册商标。

使用"Works with Apple"徽章表明该配件经过特殊设计,专门与徽章中指定的技术相 匹配,并且已获得开发者认证,满足Apple性能标准。 Apple是Apple Inc.在美国和其他国家/地区注册的商标。




Amp

Quickstart Guide

Use banana plugs to connect your favorite speakers

Indoor, outdoor, in-ceiling or in-wall. During setup, we'll tell you when to plug Amp into a power outlet.



For more information, go to the Sonos User Guide: sonos.com/guides/Amp

Download the Sonos app You'll use it to set up and control Amp.










Already have Sonos?

Open the Sonos app and choose More > Settings > Add a Player or Sub. **Enjoy music, TV and more**

Plug in an audio device (like a turntable, CD player or computer) or connect Amp to your TV.



Control the audio using the Sonos app, your TV remote, or the controls on Amp.

Need help?

Sonos App: Help & Tips

Website: sonos.com/support

Twitter: @SonosSupport

Email: support@sonos.com

Product User Guides: sonos.com/guides

SONOS"

© 2018 Sonos Inc. All rights reserved.

Sonos, Amp and all other Sonos product names and slogans are trademarks or registered trademarks of Sonos, Inc. Sonos Reg. U.S. Pat & TM Off.

Use of the Works with Apple badge means that an accessory has been designed to work specifically with the technology identified in the badge and has been certified by the developer to meet Apple performance standards.

Apple is a trademark of Apple Inc., registered in the U.S. and other countries.