

# Energy-related Product Test Summary

Commission Regulation (EC) No 2023/826

## 1. Product Information

|                                                          |                                                  |
|----------------------------------------------------------|--------------------------------------------------|
| Manufacturer:                                            | Sonos, Inc.                                      |
| Product Name:                                            | Sub Mini                                         |
| Model Number:                                            | S37                                              |
| Product Type:                                            | Wireless Smart Speaker                           |
| Product Category as per Commission Regulation 1275/2008: | Networked Equipment with HiNA Functionality      |
| Type of network ports:                                   | Ethernet and Wi-Fi                               |
| Total Number of ports:                                   | 2                                                |
| Network ports deactivated before delivery?               | No                                               |
| Standby/Off mode available?                              | Not Applicable – Inappropriate for intended use  |
| Trigger to reactivate the equipment:                     | Wireless or wired trigger from Sonos control app |
| Performance Specification:                               | Wi-Fi 802.11a/b/g/n/ac                           |

## 2. Test Results

| Port Tested    | Network Standby Power | Limit      | Time to Standby | Result |
|----------------|-----------------------|------------|-----------------|--------|
| Ethernet       | 2.99 W                | $\leq 8$ W | < 8 min         | Pass   |
| Wireless Wi-Fi | 3.14 W                | $\leq 8$ W | < 8 min         | Pass   |

Tested per EN 50564:2011. Input voltage 230VAC/50Hz

## 3. Port Management

Wi-Fi Activation/Deactivation:

Wi-Fi can be disabled by using the Sonos app from System Settings:

Settings > System (*Sub Mini*) > Products (*Sub Mini*) > Connection > Enable WiFi / Disable WiFi  
(*Wi-Fi disable option only available when Sub Mini has an Ethernet Connection*)