


1

Sonos Move 2
を電源に接続する



USB-Cポート

付属の充電ベース以外で充電するには、互換性のあるUSB-PD充電器をご使用ください。

充電ベース

充電ベースを電源に挿し込み、Sonos Move 2をベースに置きます。

2



Sonosアプリをダウンロードして設定します。



Sonosアプリを開いて[追加]をタップするか、[設定]>[システム]>[製品を追加する]に移動します。

操作ガイド

WiFiを使用して、Sonos Move 2を設定。
コンテンツをWiFiやBluetooth®
でストリーミング再生。



電源

短く押すと電源がオンに、もしくはスリープモードになります。長押しすると電源がオフになります。



Bluetooth

長押しすると新しいデバイスをペアリングし、短く押すと再接続します。



マイクのスイッチ

オフにすると、音声サービスなどマイクを使用する機能はすべて利用できなくなります。



音声サービス

タップしてオン/オフを切り替えます。




曲戻し



再生/ 一時停止



曲送り



音量を下げる

左へスライド操作
(または[-]をタップ)

音量を上げる

右へスライド操作
(または[+]をタップ)



グループ化

長押しするとSonos製品をグループ化します。

注：音声操作は、一部の国では未対応です。この機能は、お住まいの地域でSonosが音声サービスに対応次第、ご利用いただけるようになります。

サポート

カスタマーサポート
sonos.com/support

ユーザーガイド
sonos.com/guides/move2

Terms of Use, License and Warranty
www.sonos.com/legal/terms-of-use

ご利用規約、ご使用許諾契約
www.sonos.com/legal/terms-of-use

© 2023 Sonos, Inc. All rights reserved. Sonos®, Sonos Move 2, and Move 2 are trademarks or registered trademarks of Sonos, Inc. *Reg. U.S. Pat & TM Off.

© 2023 Sonos, Inc. All rights reserved. Sonos®, Sonos Move 2およびMove 2は、Sonos, Inc. の商標または登録商標です。*Reg. U.S. Pat. & TM Off.



Move 2

設定

English – Set Up

1. **Connect Move 2 to power. USB-C port** - Use a compatible USB-PD charger for charging on the go. **Charging base** - Plug the charging base into a power outlet and put Move 2 on the base.
2. **Download the Sonos app for setup.** Open the Sonos app and tap Add, or go to **Settings > System > Add Product.**

At a glance. Use WiFi to set up Sonos Move 2. Stream content over WiFi and Bluetooth®. **Power** - Press quickly to power on or put to sleep. Long press to power off. **Bluetooth** - Long press to pair new device. Short press to reconnect. **Microphone Switch** - When toggled off, all microphone-enabled features, including voice services, are unavailable. **Voice Services** - Tap to turn on and off. **Previous Track, Play/Pause, Next Track, Volume Down** - Slide left (or tap -), **Volume Up** - Slide right (or tap +). **Group** - Press and hold to group Sonos products.

SONOS