

1 オーディオケーブルと電源ケーブルを接続する



光オーディオケーブルを、テレビの光オーディオ出力からSonos Rayの光ポートに接続します。

2 Sonosのアプリをダウンロードする



ダウンロード済みの場合

Sonosアプリを開いて[追加]をタップするか、
[設定]>[システム]>[製品を追加する]に移動します。

操作ガイド

Sonosアプリやテレビのリモコンを使って、サウンドを再生、コントロールしましょう。Sonos Ray本体からもタッチ操作できます。

>||
再生 / 一時停止
1回押す

:||→→||→||
次のトラック
右へスワイプ

>||
グループ化
長押ししてSonos
製品をグループ化します。

::←→||→||
前のトラック
左へスワイプ

::
音量
左を押すと下がり、
右を押すと上がります。

サポート

カスタマーサポート sonos.com/support
ユーザーガイド sonos.com/guides/ray

Terms of Use, License and Warranty
www.sonos.com/legal/terms-of-use

© 2022 Sonos, Inc. All rights reserved. Sonos*, Sonos Ray, and Ray are trademarks or registered trademarks of Sonos, Inc. *Reg. U.S. Pat & TM Off.

ご利用規約、使用許諾契約、保証
www.sonos.com/legal/terms-of-use

© 2022 Sonos, Inc. All rights reserved. Sonos*, Sonos RayおよびRayは、Sonos, Inc.の商標または登録商標です。*Reg. U.S. Pat. & TM Off.



640-00832 - A

SONOS

Ray

English – Set Up

1. **Connect the audio and power cables.** Connect the optical audio cable (included) from your TV's optical audio OUT to Ray's optical port.
2. **Download the Sonos app.** Already have Sonos? Open the Sonos app and tap Add, or go to **Settings > System > Add Product**.

At a glance. Play and control audio using the Sonos app, your TV remote, or the touch controls on Ray. **Play / Pause** - Single press. **Group** - Press and hold to group Sonos products. **Volume** - Press left to decrease, right to increase. **Next Track** - Swipe right. **Previous Track** - Swipe left.

設定