


# 01 02

電源ボタンを  
押す



電源ボタン

USB-Cポート

充電するには、  
同梱のケーブルを10W USB  
電源アダプターに接続します


Sonosアプリを  
ダウンロードする



ダウンロード済  
みの場合

Sonosアプリを開いて  
[追加]をタップするか、  
[設定] > [システム] >  
[製品を追加する]  
に移動します

## 操作ガイド



お家ではWiFiで、  
外ではBluetooth®でストリーミング

Bluetooth

ペアリング音が鳴るまで電源ボタンを長押しします

> ||

再生/一時停止  
1回押す

> ||

次の曲  
2回押す

> ||

前の曲  
3回押す

> ||

グループ化・Swap機能  
長押しするとSonos製品をグルー  
プ化し、そのまま押し続けると製品  
間でオーディオをスワップします

+

音量アップ

-

音量ダウン

# サポート

## カスタマーサポート

[sonos.com/ja-jp/support](https://sonos.com/ja-jp/support)

## ユーザーガイド

[sonos.com/guides/roamsl](https://sonos.com/guides/roamsl)

ご利用規約、使用許諾契約  
[www.sonos.com/legal/terms-of-use](https://www.sonos.com/legal/terms-of-use)

© 2022 Sonos, Inc. All rights reserved. Sonos®, Sonos Roam SLおよびRoam SLは、Sonos, Inc.の商標または登録商標です。  
\*Reg. U.S. Pat. & TM Off.

© 2022 Sonos, Inc. All rights reserved. Sonos®, Sonos Roam SL, and Roam SL are trademarks or registered trademarks of Sonos, Inc. \*Reg. U.S. Pat. & TM Off.



610-00089 B

設定

## English – Set Up

1. Press the power button.  
USB-C port: To charge, connect the included cable to a 10W USB power adapter.
2. Download the Sonos app. Already have Sonos? Open the Sonos app and tap Add, or go to **Settings>System>Add Product**.

**At a glance. Bluetooth** – Press and hold the power button until you hear the pairing tone. **Play / Pause** – Single press. **Next track** – Double press. **Previous track** – Triple press. **Group or swap** – Press & hold to group Sonos products; continue holding to swap audio between them.

SONOS

# Roam SL