

セットアップ

English – Set Up

1. **Connect the power cord.** Choose a location for your Sonos Era 100 and plug it in.
2. **Download the Sonos app for setup.** Open the Sonos app and tap Add, or go to Settings > System > Add Product.

At a glance. Use WiFi to set up Sonos Era 100. Stream content over WiFi or Bluetooth®. **Volume Down** – Slide left (or tap -). **Volume Up** – Slide right (or tap +). **Previous Track. Play / Pause. Next Track. Group** – Press and hold to group Sonos products. **Voice Services** – Tap to turn on or off. **Microphone Switch** – When it's turned off, all microphone-dependent features including voice services are unavailable. **Bluetooth** – Long press to pair new device; short press to reconnect.

サポート

カスタマーサポート
sonos.com/support

ユーザーガイド
sonos.com/guides/era100

Terms of Use, License and Warranty www.sonos.com/legal/terms-of-use

ご利用規約および使用許諾契約
www.sonos.com/legal/terms-of-use

© 2023 Sonos, Inc. All rights reserved. Sonos®, Sonos Era 100, and Era 100 are trademarks or registered trademarks of Sonos, Inc. *Reg. U.S. Pat. & TM Off.


© 2023 Sonos, Inc. All rights reserved. Sonos®, Sonos Era 100およびEra 100は、Sonos, Inc.の商標または登録商標です。*Reg. U.S. Pat. & TM Off.



610-00161 - A

1

電源コードを接続する



Sonos Era 100の設置位置を決めて、電源コードを接続します。

2

Sonosアプリをダウンロードして設定します




Sonosアプリを開いて[追加]をタップするか、[設定]>[システム]>[製品を追加する]に移動します。

操作ガイド

WiFiを使用してSonos Era 100を設定する。
コンテンツをWiFiやBluetooth®でストリーミング再生する。

注：音声操作は、一部の国では未対応です。この機能は、お住まいの地域でSonosが音声サービスに対応次第、ご利用いただけるようになります。



音量を下げる
左へスライド操作
(または[-]をタップ)

音量を上げる
右へスライド操作
(または[+]をタップ)

< > || >
曲戻し 再生/一時停止 曲送り

> ||
グループ化
長押しすると複数のSonos製品をグループ化して同期再生できます

🗨
音声サービス
タップしてオン/オフを切り替えます

🎤
マイクのスイッチ
オフにすると、音声サービスなどマイクを使用する機能はすべて利用できなくなります

📶
Bluetooth
長押しすると新しいデバイスをペアリングし、短く押すと再接続します