

サポート

カスタマーサポート

sonos.com/support

ユーザーガイド

sonos.com/guides/sonosplay

Terms of Use, License and Warranty
www.sonos.com/legal/terms-of-use

© 2026 Sonos, Inc. All rights reserved. Sonos®, Play and Sonos Play are trademarks or registered trademarks of Sonos, Inc. *Reg. U.S. Pat. & TM Off.

ご利用規約、ご使用許諾契約
www.sonos.com/legal/terms-of-use

© 2026 Sonos, Inc. All rights reserved. Sonos®, Playおよび Sonos Playは、Sonos, Inc.の商標または登録商標です。
*Reg. U.S. Pat. & TM Off.



610-00230

Sonos Play

English – Set Up

1. **Press the power button.** When Sonos Play is ready to set up, the light will turn green and a welcome sound will play. Bluetooth. Mic switch. Power. USB-C port.
2. **Connect your device.** Personalize your sound and access exclusive features by downloading the Sonos app. Press and hold the Bluetooth button until the light turns blue, then connect to Sonos Play in your device's settings.

At a glance. Use WiFi to set up Sonos Play. Stream content over WiFi or Bluetooth.

Play/ Pause - Single press.

Next / previous - Double press / triple press. **Group** - Press and hold to group Sonos products. **Volume down / up.**

Power - Press quickly to power on or put to sleep. Long press to power off.

Bluetooth - Long press to pair a new device. Short press to reconnect.

Voice services - Press to turn on and off. **Microphone switch** - When toggled off, all microphone-enabled features, including voice services, are unavailable. Note: Voice control subject to regional availability.

Status light. Flashing white - Starting up. **Flashing green** - Ready to set up.

Flashing blue - Bluetooth pairing.

Solid blue - Bluetooth connected.


設定

SONOS

1

電源ボタンを押します

Sonos Playを設定する準備ができるとランプが緑に点灯し、ウェルカムサウンドが鳴ります。



2

デバイスを接続します




Sonosアプリをダウンロードして、サウンドのパーソナライズやSonos独自の機能をご利用ください。



ランプが青色になるまでBluetoothボタンを長押しし、デバイスの設定でSonos Playに接続します。

操作ガイド

WiFiを使用してSonos Playを設定。
WiFiまたはBluetoothでコンテンツをストリーミング再生。



> ||
再生 / 一時停止
1回押す

> ||
次へ / 前へ
2回 / 3回押す

> ||
グループ化
長押しするとSonos製品をグループ化します。

- / +
音量を下げる / 上げる

⏻
電源
短く押すと電源がオンに、またはスリープモードになります。長押しすると電源がオフになります。

📶
Bluetooth
長押しすると新しいデバイスをペアリングします。短く押すと再接続します。

💬
音声サービス
押してオン/オフを切り替えます。

🎤
マイクのスイッチ
オフにすると、音声サービスなどマイクを使用する機能はすべて利用できなくなります。

注:お住まいの地域によっては、音声操作をご利用いただけない場合があります。

●
ステータスランプ

白色に点滅
起動中

緑色に点滅
設定の準備完了

青色に点滅
Bluetoothでのペアリング

青色に点灯
Bluetooth 接続済み