


操作ガイド

高音も低音も極めた臨場感あふれるサウンドを体験。



3

Sonos Subをお持ちのシステムに追加する



Sonosアプリを開いて[追加]をタップするか、[設定]>[システム]>[製品を追加する]に移動します。

2

Sonos Subを床に置き、電源プラグを差し込む



スペースに合わせて縦横どちらの向きでも設置できます。

1

Sonosシステムを設定する

ご使用になるSonos製品をあらかじめSonos Subに接続しておいてください。



サブポート

カスタマーサポート
sonos.com/support

ユーザーガイド
sonos.com/guides/sub

ご利用規約、使用許諾契約
www.sonos.com/legal/terms-of-use


Terms of Use, License and Warranty
www.sonos.com/legal/terms-of-use

© 2021 Sonos, Inc. All rights reserved. Sonos[®],
および Subは、Sonos, Inc.の商標または登録商標です。
*Sonosは米国特許商標庁登録済みです。

© 2021 Sonos, Inc. All rights reserved. Sonos[®], and
Sub are trademarks or registered trademarks of
Sonos, Inc. *Reg. U.S. Pat. & TM Off.



640-00813 - A



SONOS

設定

English - Set Up

1. **Set up your Sonos system.** Make sure the Sonos product you plan to use with Sub is already set up.
2. **Place Sub on the floor and plug it in.** Standing up or lying flat. Wherever it fits best.
3. **Add Sub to your system.** Open the Sonos app and tap Add, or go to **Settings>System>Add Product.**

At a glance. Hear higher highs, feel lower lows for a more immersive sound experience.

Sub