


# 1 将Move 2连接到电源



**USB-C端口**  
使用兼容的USB-PD充电器随时随地充电。

**充电座**  
将充电底座插入电源插座并将Move 2放在底座上。


# 2 下载Sonos App进行设置



打开Sonos App, 然后点按“添加”, 或转到“设置”>“系统”>“添加产品”。

# 概览

使用Wi-Fi设置Sonos Move 2。  
通过Wi-Fi或蓝牙流式播放内容。



**电源**  
短按可以开机或将其休眠。  
长按可以关机。

**蓝牙**  
长按可以配对新设备。  
短按可以重新连接。

**麦克风开关**  
关闭时, 所有与麦克风相关的功能 (包括语音服务) 都将不可用。

**语音服务**  
点按可以打开或关闭。

**上一首** **播放/暂停** **下一首**



**减小音量** **增大音量**  
向左滑动 (或者点按-) 向右滑动 (或者点按+)

**分组**  
按住以对Sonos产品进行分组。

注: 并非所有国家/地区都支持语音控制。Sonos和语音服务提供商在您所在地区共同推出语音服务后, 即可使用此功能。

# 帮助

## 客户支持

sonos.com/support

Terms of Use, License and Warranty  
www.sonos.com/legal/terms-of-use

© 2023 Sonos, Inc. All rights reserved. Sonos®, Sonos Move 2, and Move 2 are trademarks or registered trademarks of Sonos, Inc.\*Reg. U.S. Pat & TM Off.



## 用户指南

sonos.com/guides/move2

使用条款、许可与担保协议  
www.sonos.com/legal/terms-of-use

© 2023 Sonos, Inc. 保留所有权利。Sonos®、Sonos Move 2和Move 2是Sonos, Inc. 的商标或注册商标。\*Reg. U.S. Pat & TM Off.

## Move 2

# 设置

### English – Set Up

1. **Connect Move 2 to power. USB-C port** - Use a compatible USB-PD charger for charging on the go. **Charging base** - Plug the charging base into a power outlet and put Move 2 on the base.
2. **Download the Sonos app for setup.** Open the Sonos app and tap Add, or go to **Settings > System > Add Product.**

**At a glance.** Use WiFi to set up Sonos Move 2. Stream content over WiFi and Bluetooth®. **Power** - Press quickly to power on or put to sleep. Long press to power off. **Bluetooth** - Long press to pair new device. Short press to reconnect. **Microphone Switch** - When toggled off, all microphone-enabled features, including voice services, are unavailable. **Voice Services** - Tap to turn on and off. **Previous Track, Play/Pause, Next Track, Volume Down** - Slide left (or tap -), **Volume Up** - Slide right (or tap +). **Group** - Press and hold to group Sonos products.

### 繁體中文 – 設定

1. 將 **Move 2** 連接到電源。 **USB-C 連接埠** - 隨時使用相容的 USB-PD 充電器充電。 **充電座** - 將充電底座插入電源插座，然後將 Move 2 放在底座上。
2. **下載 Sonos 應用程式進行設定。** 打開 Sonos 應用程式並輕觸「新增」，或前往「設定」>「系統」>「新增產品」。

**簡介。** 使用 WiFi 設定 Sonos Move 2。透過 WiFi 或 Bluetooth® 串流內容。 **電源** - 快速按下可開放電源或進入睡眠狀態。長按可關閉電源。 **藍牙** - 長按可配對新裝置。短按可重新連接。 **麥克風開關** - 關閉時，所有需要使用麥克風的功能（包括語音服務）均無法使用。 **語音服務** - 輕觸以開啟和關閉。 **上一首曲目、播放/暫停、下一首曲目、降低音量** - 向左滑動（或輕觸 - 號）。 **提高音量** - 向右滑動（或輕觸 + 號）。 **組合** - 按住可對 Sonos 產品進行分組。

SONOS