

Quickstart Guide

设置

要将 Sonos PLAY:5 添加到现有的 Sonos 系统，只需接通电源，然后从移动设备 Sonos 控制器的“设置”菜单中选择“添加播放器或 SUB”，或使用 Sonos Mac 或 PC 控制器从“管理”菜单中选择“添加播放器或 SUB”。

要设置全新的 Sonos 系统，请参考步骤 1 - 4。详细安装指导请参考 www.sonos.com/support/players

希望了解更多

网址
sonos.com/support

技术支持热线
 中文: +86 400 664 9889
 英文: +1 800 680 2345

邮件
support@sonos.com

用户手册及常见问题解答
sonos.com/guides

Set it Up

Add to an existing Sonos system:

Just plug it in and select Settings > Add a Player or SUB from the Sonos app on your mobile device, or select Manage > Add a Player or SUB when using the Sonos App for Mac or PC.

Set up a new Sonos system:

To set up a new system, follow steps 1-4 below.

Ask Us.

Website
sonos.com/support


Telephone
 China (Mandarin): +86 400 664 9889
 China (English): +1 800 680 2345

Email
support@sonos.com

Twitter
[@SonosSupport](https://twitter.com/SonosSupport)


Product User Guides
sonos.com/guides

1 接通 Sonos PLAY:5 的电源



虽然 PLAY:5 可以多种形式播放，Sonos 建议水平放置已获取更宽广的声场。

2 可选 (如果您没有 BOOST 请跳过此步)



如果您购买了 Sonos BOOST，请用包装箱内的网线连接 BOOST 任意网口到家用无线路由器的 LAN 口，然后接通电源。

将 Sonos BOOST 或任意一台 Sonos 播放器用网线连接到路由器可以建立专门用于 Sonos 系统的坚固岩石独立无线网络，否则 Sonos 系统将使用您家中现有的无线网络。有关更多产品安装信息，请访问 www.sonos.com/rock-solid-wireless

1 Connect your Sonos PLAY:5 to power

While the PLAY:5 is designed to produce great sound wherever it's placed, Sonos recommends horizontal orientation for a wide sound stage.

2 Optional

If you purchased a Sonos BOOST, connect it to your router now with an Ethernet cable (supplied) and plug it into power. Otherwise, please skip this step.

Note: Connecting a Sonos BRIDGE, BOOST or Sonos player to your router with an Ethernet cable creates a separate rock-solid wireless network exclusively for your Sonos speakers. If you don't connect the Ethernet cable, Sonos joins your home's wireless network. For more information, go to www.sonos.com/rock-solid-wireless.

3 下载和安装 Sonos 控制器软件



手机/平板电脑
 下载移动设备 Sonos 控制器
 (从 App Store 或国内主流安卓应用市场)

Mac / PC
 下载 Mac 或 PC 版 Sonos 控制器
 (地址: www.sonos.com/install)

在设置您的 Sonos 系统之前，您需要先下载并安装 Sonos 控制器软件 (参考下图及说明)，然后打开并按照屏幕上的指示设置 Sonos 系统。

- 在设置过程中:
- 系统会提示您按下然后松开 Sonos 产品上的一个或多个按钮，以便将该产品添加到 Sonos 系统。
 - 如果您选择用网线将 Sonos 产品连接到无线路由器，请在设置过程中先添加该产品。
 - 系统可能会提示您更新 Sonos 产品。此操作需要几分钟时间，具体取决于您的网络连接状况。
 - 在所有设备设置完成后，您会被要求使用常用的邮件地址和所在国家来注册您的 Sonos 系统。请务必完成注册，以开启所在国家的在线音乐服务及获取免费的软件更新。



3 Download a Sonos controller app

The Sonos controller app is required to set up your Sonos system (download instructions below). Please download the app, launch it, and then follow the on-screen prompts to set up your Sonos system.

- During the setup process:
- If you are connecting a Sonos product to your router, please add it first during the setup process.
 - You will be prompted to press and release one or more buttons on your Sonos products to add them to your Sonos system.
 - You may be prompted to update your Sonos products. This can take several minutes depending on your network connection.
 - You will be prompted to register your Sonos system. Be sure to register to receive free future software updates as well as music selections specific to your country.
- Mobile / Tablet (recommended)
 Download the Sonos controller app from the store on your device
- Mac / PC
 Download the Sonos controller for Mac or PC from www.sonos.com/install

4 设置音乐

打开 Sonos 控制器，进入音乐选择菜单


- 添加音乐服务 — 通过它添加您的在线音乐服务。
 - 音乐库 (本地共享音乐) — 播放存储在您的计算机或任何本地网络硬盘 (NAS) 中的音乐，建议使用 Mac 或 PC 上的 Sonos 控制器软件预先配置并添加您的本地音乐，方法是从设置菜单中选择音乐库 (本地共享音乐) 设置。
 - 电台 — 访问众多互联网电台。
- 有关完整的音乐选择列表，请访问 www.sonos.com/music

4 Play music

Make a selection from the Sonos music menu.

- Radio. Select from more than 100,000 free Internet radio stations, podcasts and shows.
 - Add Music Services. Explore and manage your music services.
 - Music Library. Play music stored on your computer or any Network-Attached Storage (NAS) device. If you have music on your computer, use the Sonos Controller App for Mac or PC to set up your music library.
- For a full list of music choices available in your country, go to www.sonos.com/music


触摸控制



音量减 播放/暂停 音量加




向右滑下一曲



向左滑上一曲

PLAY:5 的简单触摸界面让您方便的控制音乐。

Touch Controls



Volume Down Play/Pause Volume Up



Swipe right for next track (when applicable)



Swipe left for previous track (when applicable)

PLAY:5's simple touch interface gives you convenient control of the music.

"Made for iPod," "Made for iPhone," and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance.



SONOS

