Sonos One

快速入门指南

下载 Sonos app

您需要使用Sonos app来设置和控制One。









已下载Sonos?

打开Sonos app, 然后选择"更多">"设置" > "添加播放器或Sub"。








让家中充满音乐

您可以通过使用Sonos app、语音控制或者One上的触摸控件来播放 和控制音乐服务中的音频。



向左滑动可播放上一曲目

向左滑动播放上一首





备注: 并非所有国家/地区都支持语音控制: 当Sonos和语音服务提供商在您所在地区共同 推出语音服务后,即可使用此功能。

Sonos App:

帮助和提示

网址

sonos.com/support

邮件

support@sonos.com

用户手册及常见问题解答 sonos.com/guides

SONOS®

技术支持热线

中文: +400 664 9889

英文: +1 800 680 2345



Sonos One

Quickstart Guide

Download the Sonos app
You'll use it to set up and control your One.





Already have Sonos?

Open the Sonos app and choose

More > Settings > Add a Speaker or Sub.



Need help?

Sonos App:

Help & Tips

Website:

sonos.com/support

Email:

support@sonos.com

Product User Guides: sonos.com/guides

Telephone: China (Mandarin):

+400 664 9889

China (English):

+1 800 680 2345

10/ /" / " " \ /" /0/

Fill your home with sound

Play/Pause

Volume down

Swipe right for next track

Note: Voice control is not supported in every country yet—this feature will be available as soon as Sonos and a voice service launch together in your region.

Play and control the audio from any of your music services using the

Microphone on/off

- Status indicator light

Volume up

Swipe left for previous track

Sonos app, your voice, or the touch controls on your One.